

WIND INSTRUMENTS



E Flat Alto Saxophone

Type: **Alto Be**
Key: **Eb; E-Flat**
Material: **Brass**



B Flat Baritone

Type: **Baritone**
Key: **B Flat**
Material: **Brass, Phosphor Copper**



F-Key French Horn

Type: **Single-Row 3 Key**
Key: **F-Key**
Material: **Brass**



Bb Pocket Trumpet

Type: **Pocket Trumpet**
Key: **Bb**
Material: **Brass**



Eb Alto Trombone

Type: **Alto Trombone**
Key: **Eb**
Material: **Brass**



Bb Trumpet

Type: **Trumpet**
Key: **Bb**
Material: **Cupronickel, Brass**



Flat B Clarinet

Type: **17 Keys Clarinet**
Key: **Flat B**
Material: **Bakelite, Nickel plated keys**



16 Keys C Flute

Type: **16 Keys Closed Hole**
Key: **C**
Material: **Cupronickel**